# **Service Schematics**

### Introduction



**RH-29** 

#### **IMPORTANT:**

This document is intended for use by authorized NOKIA service centers only.

"Service Schematics" was created with focus on customer care.

The purpose of this document is to provide further technical repair information for NOKIA Ngage QD phones on Level 3/4 service activities.

It contains additional information such as e.g. "Component finder",

"Frequency band table" or "Antenna switch table".

The "Signal overview" page gives a good and fast overview about the most important signals and voltages on board.

Saving process time and improving the repair quality is the aim of this document. It is to be used additionally to the service manual and other training or service information such as Service Bulletins.

#### All measurements were made using following equipment:

Nokia repair SW : Phoenix version A13 2004.08.5.42

: Fluke PM 3380A/B Oscilloscope

Spectrum Analyzer : Advantest R3131 with an analog probe

RF-Generator / GSM Tester : Rhode & Schwarz CMU 200

Multimeter : Fluke 73 Series II

While every endeavour has been made to ensure the accuracy of this document, some errors may exist. If the reader finds any errors, NOKIA should be notified in writing.

Nokia GmbH Please send to:

Service & Competence Center Europe

Meesmannstr.103

D-44807 Bochum / Germany Email: training.sace@nokia.com


#### Copyright © NOKIA


This material, including documentation and any related computer programs is protected by copyright, controlled by NOKIA. All rights are reserved. Copying, including reproducing, modifying, storing, adapting or translating any or all of this material requires the prior written consent of NOKIA. This material also contains confidential information, which may not be disclosed to others without the prior written consent of NOKIA.





<b>Table of Contents</b>	Page
Frontpage	1
DCT-4 Common Baseband	2
UEMK	3
UPP&Memories	4
Audio	5
User Interface	6
Bluetooth	7
RF-part	8
Signal overview	9
Component finder	10


## Exploded view and component disposal




















Band	Channel	RX	VCO/RX	VC/RX	TX	VCO/TX	VC/TX
GSM 900	37	942,4MHz	3769,6MHz	~2.6V	897,4MHz	3589,6MHz	~1.8V
GSM 1800	700	1842,8MHz	3685,6MHz	~2.2V	1747,8MHz	3495,6MHz	~1.4V







I Page 9(10)

В		C224	Ī5	C395	К9	C816	T5	R135	I3	R710	Р8
B190	M5	C225	K4	C396	I10	C817	U5	R139	U7	R711	P8
	-			_				_		-	
B601	04	C226	J5	C398	J10	C818	T9	R140	U6	R712	R7
C		C227	M4	C430	D7	C819	T2	R141	Q1	R715	07
C100	Н6	C228	M5	C431	E3	C820	T8	R142	I3	R716	07
C101	J8	C229	M5	C432	D3	C821	T8	R143	I3	R717	N5
C102	Н9	C230	<b>T</b> 4	C470	K1	C822	<b>S9</b>	R144	I3	R720	Q6
C103	I6	C231	<u>J</u> 4	C471	N7	C823	S5	R160	L10	R721	R6
C104	I6	C232	K5	C472	N7	C824	58	R162	L10	R725	Р6
C105	I9	C233	Ţ4	C473	M7	C826	T4	R170	G9	R726	
			_	_						-	Q6
C106	Н9	C261	G2	C474	M8	C827	T5	R190	M7	R727	Q7
C107	Н9	C262	G3	C475	M7	C834	U5	R191	К8	R730	R8
C108	G6	C263	G3	C476	K2	C835	S2	R192	J4	R731	Q9
C109	Н9	C265	G2	C477	K1	C836	S2	R193	J4	R732	Р6
C110	I6	C300	L8	C478	K2	C837	T2	R194	Ţ4	R733	Р6
C111	G9	C301	L8	C479	K1	C871	P4	R195	<u>J</u> 4	R801	U4
C112	G6	C302	K8	C492	N8	D		R198	<u>J.</u>	R802	V5
	-					_	117				_
C130	02	C310	I4	C602	Н9	D100	H7	R199	L3	R803	T4
C131	02	C311	I5	C603	H10	D130	P2	R261	G2	R805	S9
C132	02	C312	I5	C605	P4	D190	K6	R262	G3	R817	T8
C133	02	C313	D5	C606	P4	D310	E8	R310	J5	R818	T8
C134	N2	C314	D5	C607	P4	D311	E5	R330	C6	R819	S8
C139	J1	C315	D7	C608	Q5	D312	H5	R331	C6	R820	T8
_	_				ì	F	113				_
C140	I1	C316	D8	C610	R9		1410	R332	B6	R821	T8
C141	I1	C317	D7	C615	P4	F380	M10	R333	C5	R822	T9
C142	K3	C318	D8	C616	P4	G		R334	М3	R823	T9
C144	J1	C319	D8	C620	Q4	G190	Q9	R335	L4	R824	U8
C145	G8	C320	D8	C622	Р6	G701	09	R336	L5	R825	U8
C146	G8	C321	D8	C623	05	L		R337	L4	R826	U8
C147	G8	C330	B6	C624	05	L130	Q2	R338	K4	S	
				_					-		1/7
C149	G8	C331	C6	C625	06	L131	02	R339	K4	S130	٧7
C161	L10	C332	C6	C626	P7	L260	F2	R340	K5	T	
C170	G9	C334	C5	C627	P7	L330	<b>C4</b>	R344	B6	T701	Q7
C190	M6	C336	M4	C628	05	L341	L5	R346	E1	T702	R9
C191	M4	C337	L5	C629	05	L380	M10	R347	<b>C</b> 5	V	
C192	18	C338	L4	C631	04	L381	L8	R349	L4	V130	P2
C193	L5	C339	L4	C632	04	L382	I9	R350	K5	V130	N2
					_	_					
C194	J8	C340	L4	C633	06	L384	I8	R381	R3	V132	J3
C195	M7	C341	L4	C634	Q4	L430	D3	R382	M4	V133	Н9
C196	J5	C342	K5	C635	05	L431	E3	R384	Q2	V134	Н9
C197	J6	C344	K5	C636	P6	L603	Q5	R385	R2	V165	L9
C198	M7	C345	K4	C640	T3	L604	05	R386	I9	V380	М9
C199	M5	C346	K4	C642	S3	L606	Q4	R387	K8	V601	Н9
C200	M5	C347	K4	C650	U3	L607	04	R388	I9	V801	U5
	-			_			`				
C201	J5	C348	K4	C706	06	L701	N5	R389	J9	V802	T8
C202	K8	C349	В7	C707	06	L702	N5	R390	Q2	Х	
C203	Ј8	C350	В7	C710	P8	L705	Q6	R392	I8	X130	N9
C204	J8	C353	D1	C711	Р9	L706	P6	R430	C3	X131	I2
C205	K8	C355	E1	C712	P8	L707	Р6	R431	E3	X132	F9
C206	K8	C356	B5	C715	07	L708	Q6	R432	D8	X133	F9
C207	K8	C357	B5	C716	07	L712		R470	K1	X260	E2
			_	_			Q7				
C208	L8	C358	L4	C717	05	L801	U4	R473	M7	X382	Q3
C209	M8	C359	K4	C718	N5	L806	T8	R474	K2	X470	I4
C210	M5	C360	L4	C719	05	L808	S5	R601	Н9	X471	N5
C211	M8	C380	Q2	C721	Q7	L809	S2	R602	Н9	Z	
C212	М6	C381	R3	C722	Q7	N		R603	Н9	Z130	K2
C213	M6	C382	N9	C731	P7	N260	G2	R605	N6	Z300	L8
C214	-	-		C740			B5		-	Z301	
	M7	C383	F8	_	R8	N330		R606	P3		F8
C215	M7	C384	К9	C741	8Q	N380	Q1	R610	P4	Z302	K8
C216	J5	C385	K8	C742	Q8	N430	D5	R612	P4	Z601	T3
C217	M8	C386	I10	C803	U4	N470	N7	R623	06	Z602	R5
C218	М8	C387	L9	C804	۷5	N601	P5	R626	Р3	Z604	R4
C219	M5	C389	N9	C805	U5	N801	T6	R627	H10	Z701	Р7
C220	M6	C390	R2	C810	S5	R		R630	05		Ħ.
	-						TE			$\vdash$	<del>                                     </del>
C221	M6	C391	R2	C813	T5	R100	I5	R706	06		
C222	M6	C393	K9	C814	T5	R101	G8	R707	06	_	
C223	L8	C394	К9	C815	S4	R130	02	R708	06		

